

# Launchtech.co.uk - Procedures

**Manufacturer: Renault**

**System: Service Light Reset**

## How to Reset Service Indicator of Renault Laguna II

### Method 1, manual procedure to reset service light, Laguna II 01-05:

1. Put the key in and turn on ignition (engine not running)
2. Press the button on the right stalk until the display flashes the spanner symbol and shows the miles to the next service.
3. Now press and hold the mileage reset button until the display has flashed 8 times
4. Release the mileage reset button and the new service interval will be displayed

### Method 2, manual procedure to reset service light, Laguna II 05+:

1. Put the key in and turn on ignition (engine not running)
2. Press the button on the right stalk until the display flashes the spanner symbol and shows the miles to the next service.
3. Press and hold the button on the stalk until the display has flashed 8 times
4. Release the mileage reset button and the new service interval will be displayed

[www.launchtech.co.uk](http://www.launchtech.co.uk)