

## **X431 Master screen calibration**

The below procedure will show you how to recalibrate the touch screen on the Launch X431 Master. You would need to perform this function if your touch screen is not responding or working.

1. Power the X431 device up
2. Within 3-4 seconds of powering up a message will quickly appear on the screen which says do you want to recalibrate the screen?
3. When you see this message press the “Hot Key” button 2-3 times in quick succession. The “Hot Key” button is the one above the “Power” button
4. Once you access the screen calibration mode, the display will be black with a cross hair in the middle.
5. Using the stylus or a blunt pointed pen, press and hold in the middle of the cross hair for 2-3 seconds and let go.
6. The cross hair will move to each corner, repeat step 5 again
7. Once all points have been calibrated, a confirmation message will appear briefly and the system will load as normal.
8. When X431 software has loaded up on the screen, press the “Hot Key” button and the X431 diagnostic menu will appear, use tool as normal.